

# MODEL 2010ECL-115

## RMS Signal Monitor Operations Manual

### Addendum to the 2010ECL Operations Manual Firmware Version 16AL01xx

1) Section 8.1.1, Power Requirements

Modify this section to read:

Operating Line Frequency ..... 50  $\pm$ 3Hz

EBERLE DESIGN INC.

3510 East Atlanta Avenue Tel (480) 968-6407  
Phoenix, AZ 85040 USA Fax (602) 437-1986  
www.EDIttraffic.com



