

MODEL D2010ECL

RMS Signal Monitor Operations Manual

Addendum to the 2010ECL Operations Manual Firmware Version 16AL02xx

1) Section 8.2, Dual Indication Long (SEL10) Jumper is installed

Dual Indication Long	(no fault).....	less than 700 milliseconds
	(fault).....	greater than 1000 milliseconds
	(typical)	850 milliseconds

2) Section 4.5.4, Red Interface Cable Fault Select (SEL4) Jumper is installed

The Red Interface Cable check has been enabled.

