

# SSM-12LEC-DEL

## RMS Signal Monitor Operations Manual

### Addendum to the SSM-LEC Operations Manual Firmware Version 12LC07xx

1) Option Dip Switch Programming

Modify Section 5.4.1 to read:

Option GY-Dual Indication Monitoring Enable is always ON.

2) Option Dip Switch Programming

Modify Section 5.4.4 to read:

Option Walk Disable is always ON.

EBERLE DESIGN INC.

3510 East Atlanta Avenue Tel (480) 968-6407  
Phoenix, AZ 85040 USA Fax (602) 437-1996  
www.EDIttraffic.com



