This software is for cabinet test and for custom applications ONLY.

To run the SIU Front Panel software, you must set the com port to the correct number.

- 1. First, connect the serial port to the computer with a null modem cable.
- 2. In the search screen type "Device Manager"

봂	De	vice	Manager	-	×
53		Acti	- View Hele		
		ACU			
0	-				
~		TIM	ISURFACEBK		^
	>	4	Audio inputs and outputs		
	>	\$	Batteries		
	>	-	Biometric devices		
	>	8	Bluetooth		
	>	۹	Cameras		
	>	-	Computer		
	>	-	Disk drives		
	>	-	Display adapters		
	>	Ĭ	Firmware		
	>	AN)	Human Interface Devices		
	>	-	Imaging devices		
	>	-	Keyboards		
	>		Mice and other pointing devices		
	>		Monitors		
	>	7	Network adapters		
	~	Ŵ	Ports (COM & LPT)		
			USB Serial Port (COM10)		
			🛱 USB Serial Port (COM15) 🛛 🚽		
			USB Serial Port (COM9)		
	>	а	Print queues		
	>		Processors		
	>		Security devices		
	>		Sensors		
	>	P.	Software components		
_	1	8	Software devices		~

- 3. Look to see where the USB Serial Port is. In this case were using com9.
- 4. Go to the SIU Front Panel icon and right click.



5. Go to properties and select.

6. Under Target type and the column that the serial port is using. In this case we will change it from 5 to 9.

From "C:\Program Files (x86)\SIU FrontPanel\SIU_FP.exe" /comm=5

To "C:\Program Files (x86)\SIU FrontPanel\SIU_FP.exe" /comm=9

SIU FrontPanel Properties X								
Security General	Details Shortcut	Previous Vers Compatib	ions ility					
SI	SIU FrontPanel							
Target type:	Application							
Target location: SIU FrontPanel								
Target:	Target: iles (x86)\SIU FrontPanel\SIU_FP.exe" /co							
Start in:	"C:\Program Files (x86)\SIU FrontPanel"							
Shortcut key:	None							
Run:	Normal window \sim							
Comment:	SIU FrontPanel							
Open File Lo	cation Change	Change Icon Advanced.						
OK Cancel Apply								

7. Hit the OK key and double click on the SIU Front Panel software Icon to start the software.

