



**Reno A&E**  
 4655 Aircenter Circle  
 Reno, NV 89502-5948 USA  
 Telephone: (775) 826-2020  
 Fax: (775) 826-9191  
 Website: www.renoae.com  
 E-mail: contact@renoae.com



**Reno A&E**  
 4655 Aircenter Circle  
 Reno, NV 89502-5948 USA  
 Telephone: (775) 826-2020  
 Fax: (775) 826-9191  
 Website: www.renoae.com  
 E-mail: contact@renoae.com



Since 2000


## MODEL PLH-R

### PREFORMED LOOP INSTALLATION INSTRUCTIONS

#### Installation:

1. Make a trench that the loop and lead-in cable will be placed in.
2. Place the PLH-R Preformed Loop in the trench in the proper position and orientation.
3. Use the metal corner brackets to hold the loop cable in place.
4. Route the lead-in cable to the desired termination point.
5. Fill the trench and cover the loop and lead-in cable with the roadway material removed in Step 1. Be sure to bury the loop and lead-in cable deep enough to ensure that the loop and lead-in cable are protected from vehicle traffic.

NOTE: Loop detection height is typically 2/3 the length of the shortest leg of the loop. Keep this fact in mind when determining how deep to make the trench (Step 1).



## MODEL PLH-R

### PREFORMED LOOP INSTALLATION INSTRUCTIONS

#### Installation:

1. Make a trench that the loop and lead-in cable will be placed in.
2. Place the PLH-R Preformed Loop in the trench in the proper position and orientation.
3. Use the metal corner brackets to hold the loop cable in place.
4. Route the lead-in cable to the desired termination point.
5. Fill the trench and cover the loop and lead-in cable with the roadway material removed in Step 1. Be sure to bury the loop and lead-in cable deep enough to ensure that the loop and lead-in cable are protected from vehicle traffic.

NOTE: Loop detection height is typically 2/3 the length of the shortest leg of the loop. Keep this fact in mind when determining how deep to make the trench (Step 1).

